

ProCom	Description
Infra-Red Plaque	
ML060HPH	6K BTU 1 Plaque Manual, Propane
MN060HPH	6K BTU 1 Plaque Manual, Natural
ML100HPH	10K BTU 2 Plaque Manual, Propane
MN100HPH	10K BTU 2 Plaque Manual, Natural
ML150HPH	15K BTU 3 Plaque Manual, Propane
MN180HPH	18K BTU 3 Plaque Manual, Natural
ML250HPH	25K BTU 5 Plaque Manual, Propane
MN300HPH	30K BTU 5 Plaque Manual, Natural
ML100TPH	10K BTU 2 Plaque Tstat, Propane
MN100TPH	10K BTU 2 Plaque Tstat, Natural
ML150TPH	15K BTU 3 Plaque Tstat, Propane
MN180TPH	18K BTU 3 Plaque Tstat, Natural
ML250TPH	25K BTU 5 Plaque Tstat, Propane
MN300TPH	30K BTU 5 Plaque Tstat, Natural
ML170EHPC	17K BTU 3 Plaque, Fan, Touch Pad, Propane
MN200EHPC	20K BTU 3 Plaque, Fan, Touch Pad, Natural
ML250EHPC	25K BTU 5 Plaque, Fan, Touch Pad, Propane
MN300EHPC	30K BTU 5 Plaque, Fan, Touch Pad, Natural
Blue Flame	
ML060HBH	6K BTU Manual, Propane
MN060HBH	6K BTU Manual, Natural
ML100HBH	10K BTU Manual, Propane
MN100HBH	10K BTU Manual, Natural
ML200HBH	20K BTU Manual, Propane
MN200HBH	20K BTU Manual, Natural
ML300HBH	30K BTU Manual, Propane
MN300HBH	30K BTU Manual, Natural
ML100TBH	10K BTU Tstat, Propane
MN100TBH	10K BTU Tstat, Natural
ML200TBH	20K BTU Tstat, Propane
MN200TBH	20K BTU Tstat, Natural
ML300TBH	30K BTU Tstat, Propane
MN300TBH	30K BTU Tstat, Natural
ML200EHBC	20K BTU, Fan, Touch Pad, Propane
MN200EHBC	20K BTU, Fan, Touch Pad, Natural
ML300EHBC	30K BTU, Fan, Touch Pad, Propane
MN300EHBC	30K BTU, Fan, Touch Pad, Natural
Blower	
PE06-Y-JLF-B	Blower for 15K-30K BTU Heater

All heaters come with feet for floor installation. The Touchpad units come with a digital screen with clock, electronic thermostat, electronic ignition, electronic timer, and blower. The Touchpad units must be plugged in, but can be manually operated in power outages.



PROCOM



*Infra-Red Plaque Heater Manual
 Infra-Red Plaque Heater Tstat*



*Infra-Red Plaque Heater
 Touch Pad*



*Blue Flame Heater Manual
 Blue Flame Heater Tstat*



*Blue Flame Heater
 Touch Pad*